



Planter Area Water Drainage System

List of Tools Needed, Shopping List, and Installation Instructions



Medium Capacity



5-7 Hours
Total Man Hours



\$75- \$95
Material Costs



12 Tools Needed

Tools Needed

 Concrete Saw	 Saw	 Level	 Measuring Tape	 Pick
 PVC Glue	 Shovel	 Plastic or Tarp	 Trenching Machine Optional	 Clear Waterproof Silicone

Shopping List

Quantity needed of each part will vary based on several factors specific to your project including system length, rainfall intensity, and number of problem areas. Pipe and fittings are offered in two sizes: 3" and 4". Size availability will vary based on region and store. Ensure that component sizes are consistent throughout your drainage system.

NDS Part Number	Description	Purchase Online
-----------------	-------------	-----------------

321 or 421	3" or 4" Pop-up Emitter with Elbow	Buy online
FWAS24	Flo-Well	Buy online
FWSD69	Flo-Well Surface Drain	Buy online
80	6" Atrium Grate	Buy online
Generic	3" or 4" Drain Pipe	
101 or 201	Spee-D Basin 1-Outlet or 2-Outlet	Buy online

Installation Instructions

Note Before You Dig

Prior to installation, have your local utility companies locate and mark the location of existing utilities. Lay out your drainage system and mark the location of trenches and individual parts to be installed with marking paint before digging. Carefully remove grass or plants that are located where the trench will be dug so they can be replanted after installation. Trenches should be dug such that they slope a minimum of 1% away from your house. Place all excavated dirt on a tarp so that it can be used later to backfill.

To speed up installation, a trenching machine can be used to dig all trenches, especially in areas with particularly hard soil. NDS drainage products have been designed to be installed in any soil type. Due to the variety of pipe types and sizes, double check that all pipe connection points are the correct size. Please follow all installation directions included with the individual parts of your drainage system. To create watertight connections between products, apply a bead of waterproof silicone to both parts and connect.

This system requires that the elevation of the Pop-Up Emitter be lower than the elevation of the area drain or the system will not drain

Step 1: Lay out system, dig trenches and holes

DOWNSPOUT RUNOFF: BEST SOLUTION - STEP 1



LAY OUT SYSTEM, DIG TRENCHES AND HOLES

Dig holes and trench for pipe, Spee-D Basin, and Flo-Well. Dry fit (no glue) the entire drainage system from the Spee-D Basin to the pop-up emitter. The Flo-Well should be installed at least 10' away from any existing structure. Measure and cut all pipe to necessary lengths. After completing each step, glue parts together.

Step 2: Install Spee-D Basin

The Spee-D Basin should be installed in a low spot in your landscape planter area. Connect a drain pipe to the Spee-D Basin. Place the atrium grate on the Spee-D Basin. A 6"

WATER IN PLANTER AREA: BETTER SOLUTION - STEP 2



INSTALL SPEE-D BASIN

SDR-35 drain pipe can be inserted into the Spee-D basin to raise the elevation of the atrium grate.

TIP: Dig the hole for the basin an additional 6" deeper than needed. Place 6" of gravel in the bottom of the hole. Drill small holes in the bottom of the basin to prevent standing water in the bottom of the basin.

Step 3: Install Flo-Well and drain pipe

WATER ON PATIO / POOL DECK: BETTER SOLUTION - STEP 4



INSTALL FLO-WELL AND DRAIN PIPE

Run drain pipe from other end of Catch Basin to the Flo-Well. Knock out the appropriate holes in the side panels of the Flo-Well where the drain pipe and EZ-Drain will be installed. Assemble the Flo-Well using the interlocking side panels. Slide the Drain Pipe and EZ-Drain through the holes in the Flo-Well side panels.

TIP: Lay the Flo-Well panels on bricks or other hard surfaces and use a hammer to knock out the holes in the side panels.

Step 4: Connect Flo-Well Surface Inlet

DOWNSPOUT RUNOFF: BEST SOLUTION - STEP 4



CONNECT FLO-WELL SURFACE INLET

Knock out the center hole of the Flo-Well lid. Place the lid on the Flo-Well side panels then place the Flo-Well Surface Inlet onto the Flo-Well lid.

Step 5: Install Pop-Up Emitter

DOWNSPOUT RUNOFF: BEST SOLUTION - STEP 5



INSTALL POP-UP EMITTER

Using a Corrugated Pipe Adapter, connect the EZ-Drain to an elbow with a weep hole. The elbow should be installed with the weep hole on the horizontal side of the elbow. Slide the Pop-up Emitter onto the elbow. An additional length of pipe can be used between the elbow and Pop-Up Emitter to bring the Pop-up emitter to the surface. The Pop-Up Emitter fits on the "bell" or "hub" end of the pipe or a pipe coupler.

TIP: To avoid damaging your Pop-Up Emitter with your lawn mower, raise the cutting level of the blades or avoid passing the mower over the Pop-Up Emitter

Step 6: Backfill and Replant

Backfill and replace any grass or plants that were removed.



BACKFILL AND REPLANT



Have Questions?

Call 1-877-412-7467 or visit us on the web NDSPRO.com